


Remote for dimmable sensors

HD02R



Attention

To reset the parameters, Please follow the steps as below:

- Step 1 Press ON, to turn on the light if it was off at the start.
- Step 2- Press any button of "Auto Mode", "Reset" and "Apply" to begin the sensor detection mode.
- Step 3 Press the button of Detection range, Hold time, Stand-by dimming level, Stand-by period and Daylight threshold one after the other in sequence.

Notes:

- 1. Every change will be automatically saved.
- 2. The sensor has a memory function that will not be erased no matter how long the short circuit lasts.